


- 2.

2.

2.1 100ASK_IMX6ULL

” ” MobaXterm micro USB


1.



a) b)

2. USB

USB Windows () “ ” “ (COM LPT)” “(COM21)”



www.drivergenius.com

3.

3 EMMC SD USB 3

BOOT CFG				
BOOT	SW1(LCD_DATA5)	SW2(LCD_DATA11)	SW3(BOOT_MODE0)	SW4(BOOT_MODE1)
EMMC	OFF	OFF	ON	OFF
SD	ON	ON	ON	OFF
USB	X	X	OFF	ON



USB SD TF EMMC EMMC

4.

windows	MobaXterm	“Session”	“Serial”	COM21
Flow Control	none	MobaXterm		



2.2 SDK

SDK VMWare BSP

